


SAKWRX 3D Print Remover

INSTRUCTIONS for USE

ALLOW 3D PRINT AND BUILD PLATE TO COOL




Before using Snap-dragon, allow the 3D print and build plate to cool to ambient temperature.

SAKWRX 3D Print Remover


INSTRUCTIONS for USE

PRESS LIGHTLY AGAINST YOUR MODEL



The 3D Print Remover should touch the side of your model lightly, at the bottom against the bed surface.

SAKWRX 3D Print Remover
INSTRUCTIONS for USE
CAUTION CAUTION CAUTION




DO NOT ANGLE
DOWN TOWARD
THE PRINT BED OR
DAMAGE MAY
OCCUR – SUCH AS
SHATTERED
GLASS.

SAKWRX 3D Print Remover

INSTRUCTIONS for USE

PULL BACK THE HAMMER TO SECOND NOTCH




Pull back the Hammer to the second line marking.

SAKWRX 3D Print Remover

INSTRUCTIONS for USE

PRESS LIGHTLY AGAINST YOUR MODEL




The 3D Print Remover should touch the side of your model lightly, at the bottom against the bed surface.

SAKWRX 3D Print Remover INSTRUCTIONS for USE RELEASE THE HAMMER



With the Body pressing lightly against your model, release the hammer. The print should come free.

SAKWRX 3D Print Remover INSTRUCTIONS for USE TROUBLESHOOTING



If you have a particularly large 3D print, or the build plate adhesion is quite strong (as with the use of Aqua Net Extra Super Hold Professional hairspray as a binder), it may require multiple "snaps" to remove the print.

Work your way around the model, snapping at all sides until the print comes off.